

STEEL FRAMING

Door and borrowed light openings should be rough-framed with steel studs and runners.

Position floor to ceiling height strut-studs vertically. Adjacent to frames, and anchor securely to top and bottom runners with 5/8" type S-12 low profile head screws. Where heavy or oversize doors are used, install an additional strut-stud at jambs.

Fabricate sill and header section from steel runners and install over (less than ceiling height door frame) and above and below borrowed light frames. Fabricate from a section of runner. Cut to length approximately 6" longer than rough opening. Slit flanges and bend web to allow attachment to adjacent vertical strut-studs.

Securely attach through web to strut-stud with 5/8" type S-12 low profile head screws.

